

# CLEAN ROOM WASTE CONTAINER 2

## LEAD LINED SHIELDS FOR RADIOACTIVE WASTE

Our range of lead lined sharps shields comprises three basic sizes and a choice of two lead thicknesses, 3mm or 6mm.

The shields are of steel construction with a lead lining. The outer surfaces have a durable epoxy stove enamel finish and inner surfaces are covered with a white plastic liner.

The top is removable for the replacement of the disposable sharps container. The top is fitted with a flip open lid to provide easy access to the opening in the container. The lid can be operated with the back of the hand to avoid possible contamination.

### Material Specifications:

Outer case: mild steel (CR4) powder coated

Lead: rolled lead BSEN12588 Code 7 or Code 5

Plastic Lining: 480 micron plastic



| Code            | Make          | Model   | Internal dimensions<br>LxWxH (mm) | External dimensions<br>LxWxH (mm) | Weight 3mm<br>(kg) | Weight 6mm<br>(kg) |
|-----------------|---------------|---------|-----------------------------------|-----------------------------------|--------------------|--------------------|
| 6BT-MBWC3/6SP60 | Rexam Sharpak | 60 Plus | 220x200x295                       | 256x256x320                       | 18                 | 26.8               |